

X48211




For the best results these decals should be applied to a gloss surface such as provided by either Xtracolor or Xtracrylix paints. Cut out the decal required and soak in warm water until the decal is released from the backing paper. Wet the area to be decaled with MICRO SET which will help to eliminate air trapped under the decal and position the decal.

After 5 or 10 minutes wet the decal with MICRO SOL which will soften the decal and ensure that it settles down over any surface detail. Allow the decal to dry for at least 12 hours. During this time some wrinkling of the decal may occur, this is normal. Do not touch the decal at this time.

Carefully check for small air bubbles and if there are any prick with a needle and apply a drop of MICRO SOL. After all air bubbles have been eliminated and the decals are dry wash the entire model with water to remove any excess decal adhesive.

When completely dry the whole model should be sprayed with a coat of Xtracolor or Xtracrylix with a coat of Flat, Satin or Gloss varnish depending on the finish required.




Harbour Road, Oulton Broad, Lowestoft, Suffolk, NR32 3LZ

Phone +44 1502 517444

+44 1502 500521 Fax



Many Thanks to:
Mr D. Fleming of the IPMS UK Harrier SIG



Paints:
The colours used on these aircraft can be found in the Xtracolor (prefix number with X) and Xtracrylix

(prefix number with XA1) range of paints.

Xtracolor Paints X001 RAF Dark Green X004 RAF Dark Sea Grey X015 RAF Light Aircraft Grey

X404 Matt Black X501 Silver X504 Exhaust

