
DETAIL SKETCHES

ASSEMBLE TWO PIECE SPINNER AND MOUNT FOUR PROP BLADES.



FOR PROP BLADES

SHAVE

HERE

ROUND

OFF

HERE

FINAL DIAMETER OF PROP IS 2.75". CUT PROP BLADE TIP OFF

FLAT SAND REAR FACE OF PROP BLADS AND AJUST PROFILE AS SHOWN.

14 dia. 450 & cut.

NOTE:

CATIONAL

COCKPIT


DETALS

THIS AIRCRAFT WAS

A THO SEATER

LEADING EDGE ADD SHANK

MADE OF SPRUE THE DOWTY-ROTOL PROP WAS TAKEN FROM A VISCOUNT AIRLINER POWER PLANT ASSEMBLY.



the Pork Antenna Location. . from screp.

Tail wheel well locator-Cut away and make T/W strut support from scrap.

NEWS A COME OF EPOST MESSES BREES-ID OF DE DISIDE SEFACE OF DE DANK PROOF TO RESCUEL FROM SHEET. A FLAT SANDERS OF THESE AND COME SOME IS SUCCESTED FOR BUST FIT. .

INTAKE RING TO AN OVAL COME

INTAKE / OIL COOLER

BUILD UP WITH SCRAP

SPINNER MUST PROTRUDE 4" FROM INTAKE RING.

MATING SURFACES OF TIP TANKS AND FUSELAGE MAY BE CONTED WITH EPOKY CEMENT AND FLAT

SANDED TO CREATE AND IMPROVED JOINING SURFACE.

ANGLE CUT

- 1/4" TUBE

OPEN EXHAUST PORT. LEAVE A SLIGHT RAISED

THIS SECTION FAIRS FROM ROUND TO OVAL

THIS SECTION TAPERS FROM RO

EDGE OPTIONAL DETAIL . Y4" CORRUGATED DRINKING STRAW SECTION TURNS THROUGH 45%

NOTE: FIT UP OF FUSELAGE MUST BEGIN AT RUDDER AND WORK TOWARD NOSE. CHECK FIT AT COCKPIT FOR ALIGNMENT OF DETAILS. TRIM LENGTH AT NOSE, MODEL IS TO BE 8.15" LONG BEFORE ATTACHING PROP.

NOTE FINAL AJUSTMENT/TRIM POINT.

USE A

SCRAP OR

SPAUL TO

MOUNT

PROP SPAFT

he die.

COLOR INFORMATION TURBO MUSTANG III

