



IMPORTANT! READ THESE INSTRUCTIONS FIRST

- Study assembly drawings carefully before darting.
- Each part is identified by a part number (14).
- Scrape paint from areas to be cemented.
- Before cement is used, check the fit of ea part.
- Use only enough cement to join parts.
- Apply cement to small parts with a toothpick.
- Use cement made for styrene plastic only.
- Allow paint to dry thoroughly before handling.
- Your model may be painted to match the bex photos.
- Follow the step numbers (s) in each assemb, drawing.
- * Refer to other assembly drawing for location.
- Refer to last page for decal and painting instructions.

5 STEP NUMBERS
32 ——PLASTIC PART NUMBERS
OPTIONAL
DO NOT CEMENT
CEMENT HERE ONLY
- REPEAT SEVERAL TIMES
REMOVE
REFER TO
DECAL

















