







P.O. Box 3956, Merrifield, VA 22116 USA ≈ 703/971-0500 FAX 703/971-8111

www.meteorprod.com

Write, call, or visit our home page to order our 120+ page catalog of decals, kits, conversions, tools, books, magazines, etc., and we'll send it to you right away!

Cutting Edge Modelworks, 2002

# A-4M Skyhawks Part 3



### **VMAT-102**

- Note narrow anti-corrosion Light Gull Gray fin leading edge leading edge.
- This jet had the early (small) rear fuselage ECM blisters and standard A-4F-type plain nose.
- This set requires Cutting Edge conversion set CEC48401, A-4M Airframe Conversion.
- Skyhawkers later flew mid-production A-4Ms in a similar scheme with fin tip hot dog antennas and nose antennas.

### VMA-331

- This jet was a very late production "Super Mike," and requires both Cutting Edge conversion sets CEC48401,
   A-4M Airframe Conversion and CEC48402, A-4M "Super Mike" Conversion.
- The thin yellow "drop shadow" on the "1st MARINE AIR WING" insignia was too fine to reliably print as a single decal. Apply the yellow decal, then apply the black decal very slightly below and to the left.
- A well known photo of this jet appeared in Koku-Fan many years ago. In keeping with Koku-Fan's propensity
  to heavily emphasize the blue color in photos (they told me it makes the photos look prettier!), the black fin
  and rudder appeared to be very dark blue. This is NOT correct. The squadron colors were BLACK and yellow,
  not blue and yellow!

## **Applying the Decals**

You probably already know all this stuff, so feel free to use your regular process; however, if you're new to aftermarket decals, here goes:

- Generally, use the Microscale Finishing System. We don't recommend extremely strong decal solvents such as Solvaset.
- Your model must have a smooth, glossy surface, as decals won't adhere well to matte surfaces. Use gloss paints
  or your favorite clear gloss overspray over matte or semigloss paint.
- Cut each subject out without trimming off the slight excess film (this helps the decal film disappear when dry).
- Put the decal in warm water that has a drop or two of liquid dishwashing soap or photo-flo for 10 seconds.
- When the decal will slide off the backing paper without forcing it, apply it to the proper position on your model.
   Slide the backing paper out from underneath.
- Gently blot off excess water and smooth out bubbles under the decal surface. If you wish, carefully brush on a mild decal softener such as Micro-Sol.
- When all decals are completely dry, gently wash off all excess decal adhesive.
- Finally, overcoat your model with a good quality gloss coat, followed by your choice of matte or eggshell clear topcoat.

### FS 595 Color Cross Reference

Light Gull Gray FS 36440

Xtracolor X137, Modelmaster 1729/1730, Gunze Sangyo H315/325, Pro

Modeler 88-0033, Polly Scale 505326

White FS 17875 Any white paint

# **Bibliography**

Photos in the personal collection of Dave Klaus Technical information and photos provided by the Kuwait Embassy Photos and technical information provided by Harry Gann, Douglas Aircraft

Special thanks to: Dave Aungst Gary Campbell Ed Miranda Harry Gann Kuwait Embassy