


LIMITED EDITION!

CED32076

A-7E CORSAIR II

Part 3, VA-86
Sidewinders



Recommended kit:
Trumpeter A-7E

**Cutting
Edge**


MODELWORKS [®]
P.O. Box 3956
Merrifield, VA 22116
USA
www.meteorprod.com

A-7E VA-86 Sidewinders

A-7E Corsair II

VA-86



BuNo159308
December 11, 1975




Nose gear door



Scrap view of left hand tank.





...available from

Meteor

Productions
Inc.

P.O. Box 3956, Merrifield, VA 22116 USA
703/440-8720 FAX 703/440-8724

www.meteorprod.com

*Write, call, or visit our home page to
order our decals, kits, conversions,
tools, books, magazines, etc., and we'll
send it to you right away!*

© Cutting Edge Modelworks, 2006



General notes

- Please note that the orange on the snake is intentionally different from the color used for the diamonds.

Applying the Decals

You probably already know all this stuff, so feel free to use your regular process; however, if you're new to aftermarket decals, here goes:

- Generally, use the Microscale Finishing System. We don't recommend extremely strong decal solvents such as Solvaset.
- Your model must have a smooth, glossy surface, as decals won't adhere well to matte surfaces. Use gloss paints or your favorite clear gloss overspray over matte or semigloss paint.
- Cut each subject out without trimming off the slight excess film (this helps the decal film disappear when dry).
- Put the decal in warm water that has a drop or two of liquid dishwashing soap or photo-flo for 10 seconds.
- When the decal will slide off the backing paper without forcing it, apply it to the proper position on your model. Slide the backing paper out from underneath.
- Gently blot off excess water and smooth out bubbles under the decal surface. If you wish, carefully brush on a mild decal softener such as Micro-Sol.
- When all decals are completely dry, gently wash off all excess decal adhesive.
- Finally, overcoat your model with a good quality gloss coat, followed by your choice of matte or eggshell clear topcoat.

FS 595 Color Cross Reference

FS 2197	FS 2197	Xtracolor X104
FS 6440	Xtracolor X137, Modelmaster 1729/1730, Gunze Sangyo H315/325, Pro Modeler 88-0033, Polly Scale 505326	
FS 7875	Any gloss white	

Bibliography

Detail & Scale C&M Vol. 9 by Bert Kinzey. Kalmbach Books, 1988.