


Hawker Hunter F.6 Pt1



Xtracolor or Xtracrylix paints. Cut out the decal required and soak in warm water until the decal is released from the backing paper. Wet the area to be decaled with MICRO SET which will help to eliminate air trapped under the decal and position the decal. After 5 or 10 minutes wet the decal with MICRO SOL which will soften the decal and ensure that it

For the best results these decals should be applied to a gloss surface such as provided by either

wrinkling of the decal may occur, this is normal. Do not touch the decal at this time. Carefully check for small air bubbles and if there are any prick with a needle and apply a drop of MICRO SOL. After all air bubbles have been eliminated and the decals are dry wash the entire model with water to remove any excess decal adhesive.

settles down over any surface detail. Allow the decal to dry for at least 12 hours. During this time some


When completely dry the whole model should be sprayed with a coat of Xtracolor or Xtracrylix Flat, Satin or Gloss varnish depending on the finish required.





Harbour Road, Oulton Broad, Lowestoft, Suffolk, NR32 3LZ


Phone +44 1502 517444 Fax +44 1502 500521

sales@hannants.co.uk










X001 BS381C:241 Dark Green X004 BS381C:638 Dark Sea Grey X015 BS381C:627 Light Aircraft Grey X019 BS381C:356 Yellow X141 Gloss White X404 Matt Black


X502 Natural Steel

Paints:

The colours used on these aircraft can be found in the Xtracolor (prefix number with X) and Xtracrylix (prefix number with XA1) range of paints.

XA1001 BS381C:241 Dark Green XA1004 BS381C:638 Dark Sea Grey XA1015 BS381C:627 Light Aircraft Grey XA1019 BS381C:356 Yellow XA1141 Insignia White







383 383

438 438

440 440 382

172 204 447