



Lancaster House, P.O. Box 50, Whitstable, Kent, CT5 2UX, GREAT BRITAIN

## Fokker D.XXIII

## CONSTRUCTION NOTES

- 1. Firstly separate all parts from Sprues, and clean off all Flash & Moulding marks.
- 2. Locate Cockpit Floor moulding, and attach the Seat, Next attach the Instrument Panel to the port fuselage half. Add the Fuel Tank to the scribed portion of the floor, when dry add the metal Nosewheel compartment. underneath (Metal parts may be attached with any 'Cyano-Acrylate' adhesive such as Superglue).
- 3. Add the completed Cockpit assembly to the PORT Fuselage half, when dry join Fuselage halves and remove the joint line.
- 4. At this point add the Nose & Tail Cowlings to the front & rear of the Fuselage. When dry add the metal Propellers.
- 5. Next, join together the upper and lower Wing & Tail Boom mouldings, When dry add the Wings to the fillets on the Fuselage checking the dihedral angle with the general arrangement drawing on the reverse of the box. When dry add the Twin Booms & Tailplane mouldings. (The slots on the Fin should point inwards). 6. Invert model and attach the U/C Legs & U/C Doors, when dry add the Main Wheels, and the Under Fins to the slots in
- the bottom of the Booms.

  7. Locate and attach the Canopy moulding. Finally, paint model
- 7. Locate and attach the Canopy moulding. Finally, paint model in accordance with the Colouring Notes, and add the transfers.





Lancaster House, P.O. Box 50, Whitstable, Kent, CT5 2UX, GREAT BRITAIN

## Fokker D.XXIII



