

Desert Air War WWII **Collection Pt1**





Xtracolor or Xtracrylix paints. Cut out the decal required and soak in warm water until the decal is released from the backing paper. Wet the area to be decaled with MICRO SET which will help to eliminate air trapped under the decal and position the decal. After 5 or 10 minutes wet the decal with MICRO SOL which will soften the decal and ensure that it

wrinkling of the decal may occur, this is normal. Do not touch the decal at this time. Carefully check for small air bubbles and if there are any prick with a needle and apply a drop of MICRO SOL. After all air bubbles have been eliminated and the decals are dry wash the entire model

settles down over any surface detail. Allow the decal to dry for at least 12 hours. During this time some

with water to remove any excess decal adhesive. When completely dry the whole model should be sprayed with a coat of Xtracolor or Xtracrylix Flat, Satin or Gloss varnish depending on the finish required.





Harbour Road, Oulton Broad, Lowestoft, Suffolk, NR32 3LZ

Phone +44 1502 517444

Fax +44 1502 500521

sales@hannants.co.uk





Xtracolor Paints

X002 Dark Earth

X009 Middle Stone

X012 Night Black

X026 Azure Blue

X031 Red

X105 Sand

X112 Olive Drab

X133 Neutral Grey X405 Matt White

X504 Exhaust

Paints:

The colours used on these aircraft can be found in the Xtracolor (prefix number with X) and Xtracrylix (prefix number with XA1) range of paints.

Xtracrylix Paints

XA1002 Dark Earth XA1009 Middle Stone XA1012 Night Black XA1026 Azure Blue

XA1031 Red

XA1105 Sand XA1112 Olive Drab

XA1133 Neutral Grey

