48-781

## AeroMaster.



Suggested Kit: 1:48 Monogram/Revell F-100D Super Sabre



Apply decal G (top right) before

glueing wing fences

## F-100D USAF SUPER SABRE

Copyright @ 02/2006

PART V North American F-100D Super Sabre 55-2796 Captain Robert Maxwell 511th. Fighter Bomber Squadron, 405th. Fighter Bomber U.S. AIR FORCE Wing, Langley Air Force Base, Virginia, May 1959. FW-796 N(N) C(D) Our thanks to Dave Menard for his advise, corrections and 52796 coaching. THANKS DAVE !!! Right side NOTE: Decal 18 was possibly applied 18(18) to both sides. S. AIR FORCE 13(13) 15L(15R) A(A) FW-558 14(14) North American F-100D Super Sabre 55-3558 'STINGER' 17L(17R) 35th. Tactical Fighter Squadron, 8th. Tactical Fighter Wing, Itazuke Air Force Base, Japan 1960. Pilot name is bogus. Recommended Kit H(H) or 12L(12R) O(O) Recommended Reference 1:48 Monogram/Revell F-100D 1. F100 Super Sabre in Color, Robert Super Sabre Robinson & David Menard, Fighting Specifications called for the USAF and Colors, Squadron/Signal Publications U.S. AIR FORCE to be painted Insignia 2. North American F-100 Super Sabre, Blue or Black, Blue being the first choice. famous Airplanes of the World No. 22, Bunrin-Do Co. Ltd. 3. USAF Europe 1948-1965 in Color, Robert Robinson, Fighting Colors, Squadron/Signal Publications Apply decal Y after nose band decals have dried On these early 1950's a/c, you want to use the refueling probe part # 8 after you shorten it 5/8 of an inch at the indicated area. Extended fuses were used only after the 1960 era. Do not use if your a/c is depicted in the 50's or tn the early 60s.