



Factory Fw 190A camouflage pattern shown.

All aircraft on this sheet should have been fairly similar to this diagram.



...available from



P.O. Box 3956, Merrifield, VA 22116 USA 203/440-8720 FAX 703/440-8724

www.meteorprod.com

Write, call, or visit our home page to order our 120+ page catalog of decals, kits, conversions, tools, books, magazines, etc., and we'll send it to you right away!

Cutting Edge Modelworks, 2005

Fw 190A "Vicious Wulfs" Part 1 __Cuttin



White 6 & Red 9

- Standard scheme of RLM 74/75/76 with a matte black distemper paint roughly applied for night operations.
- Note RLM 04 yellow rudder showing through black distemper.
- SC 250 bomb carried.
- Reportedly these aircraft had two additional recognition lights added for night operations, a green one under the starboard wing in line with the wing cannon and behind the main spar, and one under the center fuselage forward of the leading edge of the horizontal stabilizers.

White 10

- Monkey emblem was Kosse's personal emblem.
- Unknown if monkey art was applied to left side of cowl. Additional decals are provided.
- · Note there is no black painted over exhaust vents.

-+-He

- The He represents the first two letters of the pilot's surname.
- Note the unusual application of the Werk Nummer.

Applying the Decals

You probably already know all this stuff, so feel free to use your regular process; however, if you're new to aftermarket decals, here goes:

- Generally, use the Microscale Finishing System. We don't recommend extremely strong decal solvents such as Solvaset.
- Your model must have a smooth, glossy surface, as decals won't adhere well to matte surfaces. Use gloss paints
 or your favorite clear gloss overspray over matte or semigloss paint.
- Cut each subject out without trimming off the slight excess film (this helps the decal film disappear when dry).
- Put the decal in warm water that has a drop or two of liquid dishwashing soap or photo-flo for 10 seconds.
- When the decal will slide off the backing paper without forcing it, apply it to the proper position on your model.
 Slide the backing paper out from underneath.
- Gently blot off excess water and smooth out bubbles under the decal surface. If you wish, carefully brush on a mild decal softener such as Micro-Sol.
- When all decals are completely dry, gently wash off all excess decal adhesive.
- Finally, overcoat your model with a good quality gloss coat, followed by your choice of matte or eggshell clear topcoat.

FS 595 Color Cross Reference

- RLM 74 Xtracolor X206/144, Polly Scale 505059, Floquil 303247, Gunze Sangyo H068/H319, Tamiya XF62
- RLM 75 Xtracolor X207, Polly Scale 505060, Floquil 303249, Gunze Sangyo H069/H057
- RLM 76 Xtracolor X208/138, Polly Scale 505061, Floquil 303251, Pro Modeler 88-0042, Gunze Sangyo H062, Modelmaster 1731, Tamiya XF66

Bibliography

Jagdwaffe Vol.4, Sec. 1 Holding The West by D. Wadman and M. Pegg. Classic Publications, 2003.