

# "ARBA" Messerschmitt Bf110G2 1/72

(Conversion kit for 1/72 Fujimi Bf110C/D)

## PARTS LIST

### Resin Parts

- 1 : Nose
- 2 : Blank For Canopy
- 3 : Engine Block/Cowling
- 4 : Engine Block/Cowling
- 5 : Upper Cowling Bulge
- 6 : Upper Cowling Bulge

### Acetate Parts

- 15: Canopy \*

### White Metal Parts

- 7: Propeller
- 8: Propeller
- 9: Spinner
- 10: Spinner
- 11: Radiator Bath
- 12: Radiator Bath
- 13: Intake
- 14: "Zwilling" Machine Gun

### Materials Required

- 1: Cyano Adhesive ("Super Glue") or Epoxy Adhesive.
- 2: Filler ("Milliput" or similar).
- 3: Fine Wet and Dry Paper ("Flexdirt" is recommended)
- 4: White glue or Balsa Cement to attach the Canopy.

\* A RESIN BLANK IS PROVIDED TO AID CUTTING OF THE CANOPY

## SUGGESTED ASSEMBLY PROCEDURE

**NOTE : A:** Any distorted resin parts can be restored to shape by bending in WARM (Not Hot) water

**B:** Use Cyano Adhesive or Epoxy Resin.

**C:** Pre-paint as required

- 1: Assemble the Fujimi fuselage according to the kit instructions. Replace the kit nose section with the new resin item supplied (1).
- 2: Assemble wings in accordance with Fujimi instructions. a section will require careful removal from the upper cowlings of the Fujimi kit to enable replacement with the bulges supplied (5 & 6). ensure that the new cowlings supplied (3 & 4) fit neatly to the front of the wing engine mounting area. the white metal propellers (7 & 8), Spinners (9 & 10) and radiator baths (11 & 12) may be fitted at any time during construction of the kit. The intake supplied (13) should be added to the inner starboard cowling area just aft of the wing leading edge and above it.
- 3: The twin machine gun assembly (14) should be fitted inside the rear of the new acetate canopy (15) after the canopy has been carefully trimmed to fit the fuselage.

### **RECOMMENDED SAFETY PRECAUTIONS**

THIS KIT IS INTENDED FOR ADULT MODELLERS ONLY.

WE RECOMMEND THAT YOU KEEP THE PARTS OF THE KIT AWAY FROM FOODSTUFFS AND THAT CARE IS TAKEN WHEN SANDING OR FILING ANY PARTS. DUST SHOULD NOT BE INHALED OR ALLOWED TO CONTAMINATE FOOD.

HANDS SHOULD BE WASHED AFTER WORKING.

SANDING SHOULD BE CARRIED OUT USING "WET AND DRY" PAPER ("FLEXGRIT" IS RECOMMENDED.) USED WET.

CYANO OR TWO PART EPOXY ADHESIVE IS RECOMMENDED FOR ATTACHING RESIN AND WHITE METAL PARTS (SLO-ZAP<sup>®</sup> ADHESIVES ARE EASIEST TO USE).

PLEASE FOLLOW THE MANUFACTURER'S INSTRUCTIONS WHEN USING ADHESIVES AND FILLERS.