

BLICK

MODELLERS

dry print





RUB-ON LETTERS NUMBERS & STRIPES



INSTRUCTIONS FOR USING BLICK DRY PRINT

Remove backing paper from behind the plastic sheet of lettering.

Place plastic sheet with letters to be transferred in the desired position on the article to be lettered.

Rub all over the letter to be transferred with even pressure and using a ball-point pen.

Carefully peel off the plastic sheet.

Cover the letter that has been transferred with the backing paper and rub over lightly to secure good adhesion.

NOTE. In order to avoid accidental transference of unwanted letters keep the backing paper behind the plastic sheet of letters beneath letters not to be transferred.

On shiny or uneven surfaces it is often easier to use the pre-release method as follows:

Before removing the backing paper rub over the letter to be transferred using a ball-point pen, then remove the backing paper and position the letter as required. Finger pressure alone will then be sufficient to secure the transference of the desired letter. The backing paper should then be placed over the transferred letter and rubbed over to secure good adhesion.

To obtain coloured letters, the area on the model on which the letters are to appear is first painted in the colour required for the letters. Blick Dry Print is then applied in the normal way and well rubbed down. The finishing colour of the surrounding area is then painted and left to dry. When dry, a piece of self-adhesive cellulose tape is applied over the lettering and pressed down. When the tape is removed it will be found that the letters will come away with it, leaving the original colour showing through.

BLICK Modellers' Dry Print can be obtained from most good class model shops. In case of difficulty please write to:

BLICK OFFICE EQUIPMENT LTD.

(Dry Print Division)

83 COPERS COPE ROAD, BECKENHAM, KENT

