Black Box **RESIN PARTS:**


- 1. Floor
- 2. Seat
- 3. Stick
- 4. Seat Handle
- Rudder Pedals (x2)
- Right Front Side Wall
 Left Front Side Wall
- 8. Instrument Panel
- 11. Oil Reservoir
- 12. Front Bulk Head
- 13. Oxigen Bottles (x2)
- 9. Lever 1
- 10. Lever 2
- 14. Rear Compartment
- 15. Radio Housing
- 16. Radio Platform
- 17. Mid Bulk Head
- 18. Right Rear Side Wall
- Gun Mechanism 20. Gun Barrel
- 21. Gunner Seat

TBM-3 AVENGER cockpit set with gun turret update for Trumpeter kit


1/32 scale Copyright R V.M.D. Studios, Inc. 2005

IMPORTANT NOTE:

The Avenger set is complicated. Due to large size parts minor warpage may occur. These can easily be restored with the help of a hair dryer. Testfitting several times before gluing is very important. Sometimes extra trimming of the resin is required.




NOTE: Instrument panel to be installed in step 5. Extra care and trimming needed to remove the instrument panel from the casting block. Dry fit several times to coaming area to insure proper fit and alignment with fuselage halves.




STEP 3:

CORRECTION:

Part #18 needs to be corrected. Remove a strip of resin (approx. 2mm) as indicated. Align this side wall with the right fuselage half. Make sure to testfit parts #17 - #18 and #14 before gluing and trim where necessary.





Glue part #17 the same way as Trumpeter's part G68 as explained on their instructions (step 9).

REFERENCES:

TBF & TBM AVENGER - Detail & Scale #53 - Bert Kinzey TBF/TBM AVENGER - Walk Around #25 - Squadron Signal **REPLIC Magazine #64**

ACKNOWLEDGEMENTS:

As always, my gratitude goes to my dear friends the Machmaster and Lonnie Berry for their continued support.

web site: WWW.VMDSTUDIOS.COM

COMBAT SERIES -

Black Box


RESIN PARTS:

- 1. Floor
- 2. Seat
- 3. Stick
- 4. Seat Handle
- 5. Rudder Pedals (x2)
- Right Front Side Wall
 Left Front Side Wall
- 8. Instrument Panel
- 9. Lever 1 10. Lever 2
- 11. Oil Reservoir
- 12. Front Bulk Head 13. Oxigen Bottles (x2)
- 14. Rear Compartment
- 15. Radio Housing
 - 16. Radio Platform
 - 17. Mid Bulk Head
 - 18. Right Rear Side Wall
 - 19. Gun Mechanism
 - 20. Gun Barrel 21. Gunner Seat




Item # CS32029 TBM-3 AVENGER cockpit set with gun turret update for Trumpeter kit

1/32 scale Copyright ® V.M.D. Studios, Inc. 2005



- (1) Glue seat onto part A12 from Trumpeter and mount as indicated on their instructions.
- (2) Glue resin parts onto cockpit floor and use part G28 and G30 from Trumpeter as indicated on their instructions.

STEP 5:





As indicated in step 1 this area needs special attention to insure proper fit. Both coaming and instrument panel need trimming.

Glue part 16 (radio platform) same way as Trumpeter's part A8 as indicated on their instruction sheet (step 12).

Use Trumpeter's photo etch together with our set.

STEP 6:





To mount the gun turret use resin parts #19 - 20 and 21 together with Trumpeter's parts G67 - H12 - H13 - H14 H15 - H19 - H20. Refer to their instruction sheet step 26 & 27. Also use their photo etch accordingly.

REFERENCES:

TBF & TBM AVENGER - Detail & Scale #53 - Bert Kinzey
TBF/TBM AVENGER - Walk Around #25 - Squadron Signal
REPLIC Magazine #64

ACKNOWLEDGEMENTS:

As always, my gratitude goes to my dear friends the Machmaster and Lonnie Berry for their continued support.

web site: WWW.VMDSTUDIOS.COM

COMBAT SERIES -