


Parts list

- ① Frame, left half 1 ⑤ Magazine, left half 1 ⑨ Trigger 1 ⑬ Spring 2
- ② Frame, right half 1 ⑥ Magazine, right half 1 ⑩ Striker 1
- ③ Slide, left half 1 ⑦ Grip, right half 1 ⑪ Barrel Cap 1
- ④ Slide, right half 1 ⑧ Grip, left half 1 ⑫ Bullet 8

Browning.32 M1922



Set the spring ⑬ into the striker ⑩

Fit the trigger ⑨ and fix ①②

