1/144 E13A Jake

14678

Your MINICRAFT E13-A1 Jake may be assembled with an 'In-flight' feature ('spinning' propeller). Please review the assembly steps to become familiar with the parts before beginning assembly.

PARTS LAYOUT DIAGRAM





CANOPY





















E13A "Jake", 901 Kokutai, 1943



PAINTS


A Japanese Navy Sky Gray (ModelMaster 2117, Acryl 4762)

B Red-Brown (ModelMaster 1701, Acryl 4707)

C Japanese Navy Black Green (ModelMaster 2116, Acryl 4780)

D Yellow (ModelMaster 2118, Acryl 4721)

E13A "Jake", IJN Heavy Cruiser Atago, 1942



Your Minicraft model includes high-quality waterside decals. These decals adhere best to a glossy surface; and it is recommended that you apply a clear gloss coat over your painted model.

Use a sharp scissors or knife to cut individual decals from the carrier sheet. Do not cut into the clear film surrounding the individual decals.

- * It is recommended that you apply one decal at a time.
- * Place the decal section in warm water, when first inserted in the water your decal will curl, after approximately ten seconds the decal will uncurl. Remove from water and lay on a paper towel. After approximately 10 20 seconds the decal will slide freely from the backing paper. Use a small brush to help slide the decal from the backing paper and into position on the model. Carefully blot excess water from the decal, using care not to move the decal or tear it.
- * If you choose to use a setting solution, apply a thin coat over the decal following the manufacturer's instruction.
- * Allow the decal to dry overnight. Wash any adhesive residue off the model with a small amount of clean water and dry thoroughly.
- * Apply clear gloss, matte or flat coat to seal decals following the instructions from the manufacturer.



Visit our Websitewww.minicraftmodels.com

Minicraft Models (US) LLC 1501 Commerce Drive Elgin, IL 60123 Phone: 847-429-9676