48029

SILVER STARFIGHTERS

EAGLE STRIKE


productions




8L (8R)




SILVER STARFIGHTERS



F-104C-5-LO Starfighter 56-930. Assigned to 476th TFS, 479th TFW, George AFB, California, in 1959. Natural metal finish with White wings, ADC Gray (FS16473) radome, and Antiglare Green (FS34108) panel forward of the windscreen. Dark Blue squadron trim color. Note this aircraft did not yet have the tail hook installed. The inflight refueling probe was optional equipment and was carried some of the time. The 476th was the first Tactical Air Command squadron to receive the Starfighter.



F-104C-5-LO Starfighter 56-922. Assigned to 479th TFW, George AFB, California. Natural metal finish with White wings, ADC Gray (FS16473) radome, and Antiglare Green (FS34108) panel forward of the windscreen. Pitot tube White with Red stripes. Olive Drab (FS34087) stripes on wings and tail used during Operation Desert Strike exercise in the Spring of 1964. The in-flight refueling probe was optional equipment and was carried some of the time. Cut Decal J to fit around the probe.



F-104C-10-LO Starfighter 57-928. Assigned to 479th TFW, George AFB, California. Natural metal finish with White wings, ADC Gray (FS16473) radome, and Antiglare Green (FS34108) panel forward of the windscreen. Pitot tube White with Red stripes. Red stripes on wings and tail believed used during the Operation Gold Fire exercise in the Autumn of 1964 but reportedly also seen during a European deployment at about that time. The in-flight refueling probe was optional equipment and was carried some of the time.




0


SILVER STARFIGHTERS



Right Side Nose FG-930



Right Side Nose FG-922/FG-928



References:

- Photos supplied by Mr Dave Menard.

Recommended Kits:

- Hasegawa F-104 C.

Our thanks!





20R (20L)





Decaling: Apply decals only to a glossy surface.

1. With a sharp scissors or knife, carefully cut item to be used, being careful of not cutting off the clear film around it or that belonging to an adjacent item.

- 2. Submerge in clean tap water for over 10 seconds and lay over an absorbent paper towel. Decal will slide freely in about 20 seconds. Do not leave decal on water bowl over ten seconds, or adhesive quality will suffer.
- 3. With a clean brush, apply a setting solution to the area where the decal will finally lay. (Micro, Super or Aero Set will do). With a clean pointed brush slide the decal on to the final area. Allow setting solution to dry for about 3-5 minutes.
- 4. With another clean brush, apply a solvent solution over the decal (Micro, Super or Aero Sol will do). Do this if possible in one stroke since your decal will soften up and wrinkle immediately. This is an important step in the process, whatever you do DO NOT TOUCH THE DECAL, after this process until it is totally dry, preferably overnight.
- 5. When thoroughly dry, rinse your model with tap water and mild soap to wash of excess glue.
- 6. Finish your model with the desired final coat (gloss, flat, or semigloss).