


72nd Scale
NO.
72-197



F-106 DELTA DARTS #5
MICROSCALE DECAL
BY KRASEL INDUSTRIES, INC., SANTA ANA, CA. 92705

AIRCRAFT
\$2.50

Recommended Kit- Hasegawa F-106A




SPLIT VIEW SHOWING MARKINGS
COMMON TO ALL VERSIONS.


GENERAL PAINTING INFORMATION U.S.A.F. F-106 DELTA DART

- | | |
|----------------------|---|
| DARK GULL GREY | ENTIRE AIRCRAFT AND AUX. FUEL TANKS |
| BLACK | ANTI-GLARE PANEL & LEADING EDGE OF FIN TIP. |
| VERY DK. BROWN | RADOME. |
| YELLOW | COCKPIT GLASS TRIM. |
| BARE METAL | LEADING EDGES OF INTAKES, TRAILING EDGES OF
DIVE BRAKES, EXHAUST RING & BURNER CONE, GEAR
STRUTS AND WHEEL CENTERS. |
| RED | TURBINE WARNING STRIPES |
| NATIONAL
INSIGNIA | FUSELAGE 30" WINGS 40" |


F-106A 177th FIG
New Jersey ANG
Standard Painting Scheme




F-106A 186th FIS
Montana Air Guard
Standard Painting Scheme



F-106 A
California Air Guard
Standard Painting Scheme



MARKINGS COMMON TO ALL
VERSIONS




72nd Scale
NO.
72-197



F-106 DELTA DARTS #5
MICROSCALE DECAL
BY KRASEL INDUSTRIES, INC., SANTA ANA, CA 92705

AIRCRAFT
\$2.50

We wish to thank:
A.T. Lloyd and
Jack Callaway
for their assistance.



T-33A 87th FIS
Squadron Hack Aircraft
Overall ADC Gray-Glossy

THE MICRO SCALE DECAL SYSTEM

1. Surface to be decalced must have a smooth, glossy, painted finish. (Do not apply decals to unpainted surfaces or they will not adhere.) To obtain this surface either paint the model with glossy paints or spray MICRO GLOSS over matte-finish paint. IMPORTANT: Spray MICRO GLOSS over entire model or uneven patches will appear when the flat finish is added later. Allow paint to dry thoroughly.
2. For best results, surface to be decalced should be horizontal. A small vise is helpful here, or a box can be made into a jig to allow the model to lay on its side.
3. Cut each decal subject from the sheet only as needed. DO NOT cut clear film away from design. Using tweezers, dip decal completely into water then remove and allow decal adhesive to soften. About one minute should be sufficient.
4. While adhesive is softening use a soft, medium-size brush, a No. 7 red sable water color brush is ideal, and wet the area to be decalced with a few drops of MICRO SET (Blue label). This contains a wetting agent and helps eliminate tiny air bubbles.
5. Holding the decal paper with tweezers, use the brush to slide the loosened decal into the MICRO SET on the model.
6. Now place a few drops of MICRO SOL (Red label) directly onto the decal and position the decal exactly where it is to remain.

7. The MICRO SOL will soften the decal and allow it to conform exactly to the surface beneath. DURING THIS PROCESS THE DECAL WILL WRINKLE AND DISTORT. DO NOT TOUCH IT! THIS IS NATURAL AND AN IMPORTANT PART OF THE SYSTEM! As the decal dries it will flatten-out and lay down. When finally dry there will be no distortion and the decal will be permanently bonded to the paint beneath. Actual drying time will vary according to temperature and humidity.
8. When decal is dry, examine it for any air bubbles. If any are found, puncture them with a sharp needle and put a drop of MICRO SOL over the bubble and allow to dry.
9. Carefully examine the clear film to be sure no silvering has appeared. If any is present, puncture the film several times with a sharp needle and apply MICRO SOL. The silvering should vanish as the SOL touches it.
10. After the decals have dried for several hours, carefully wash the decal adhesive from the entire model.
11. After the decals have dried for at least 12 hours, complete the model by spraying with either MICRO FLAT or MICRO GLOSS, depending on the sheen desired on the finished model.

72485

14

14

80790

Big Sky Country

Montana

70240

Jersey Devils

Jersey Devils

70240

72485

14

14

80790

Big Sky Country

Montana

1974 57A Duck 544 Street Saddle

180 4A 57A Duck 544 Street Saddle


70586

70586

USAF
USAF

USAF
USAF

U.S. AIR FORCE
U.S. AIR FORCE
U.S. AIR FORCE
U.S. AIR FORCE



WARNING
KEEP CLEAR

WARNING
KEEP CLEAR

