

72nd Scale  
NO.  
48-75




A-4M SKYHAWKS  
MICROSCALE DECAL  
BY KRASEL INDUSTRIES, INC. SANTA ANA, CA. 92705


AIRCRAFT

TWO OF THE PLANES ON THIS SHEET HAVE ECM PODS ON THEM WHICH AREN'T INCLUDED IN THE KIT. SO YOU'LL HAVE TO MAKE THEM YOURSELVES.

1. FIRST, USING A SHARP KNIFE, CUT THE RUDDER STRAIGHT ACROSS AT THE TOP OF THE FIRST RIB, LIKE THIS



2. THEN SAND THE TOP OF THE RUDDER SO THAT IT'S ABOUT 1/32 OF AN INCH BELOW THE TAIL, LIKE THIS



The MICRO SCALE DECAL is the thinnest, most versatile decal made. It will conform to the irregular surfaces found on models because of its strength and flexibility. These characteristics are not found on any other decal made. When used with the MICRO SCALE SYSTEM the MICRO SCALE DECAL will help produce the most realistic model you can make.

The MICRO SCALE SYSTEM is simple to use but each step must be followed as described to assure perfect results. The elimination of any step may cause blushing (a veiling of the decal film) or an uneven finish on the completed model.

#### THE MICRO SCALE DECAL SYSTEM

1. Surface to be decalced must have a smooth, glossy, painted finish. (Do not apply decals to unpainted surfaces or they will not adhere.) To obtain this surface either paint the model with glossy paints or spray MICRO GLOSS over matte finish paint. IMPORTANT: Spray MICRO GLOSS over entire model or uneven patches will appear when the flat finish is added later. Allow paint to dry thoroughly.
2. For best results, surface to be decalced should be horizontal. A small vise is helpful here, or a box can be made into a jig to allow the model to lay on its side.
3. Cut each decal subject from the sheet only as needed. DO NOT cut clear film away from design. Using tweezers, dip decal completely into water then remove and allow decal adhesive to soften. About one minute should be sufficient.
4. While adhesive is softening use a soft, medium-size brush, a No. 7 red sable water color brush is ideal, and wet the area to be decalced with a few drops of MICRO SET (Blue label). This contains a wetting agent and helps eliminate tiny air bubbles.
5. Holding the decal paper with tweezers, use the brush to slide the loosened decal into the MICRO SET on the model.
6. Now place a few drops of MICRO SOL (Red label) directly onto the decal and position the decal exactly where it is to remain.
7. The MICRO SOL will soften the decal and allow it to conform exactly to the surface beneath. DURING THIS PROCESS THE DECAL WILL WRINKLE AND DISTORT. DO NOT TOUCH IT! THIS IS NATURAL AND AN IMPORTANT PART OF THE SYSTEM! As the decal dries it will flatten-out and lay down. When finally dry there will be no distortion and the decal will be permanently bonded to the paint beneath. Actual drying time will vary according to temperature and humidity.
8. When decal is dry, examine it for any air bubbles. If any are found, puncture them with a sharp needle and put a drop of MICRO SOL over the bubble and allow to dry.
9. Carefully examine the clear film to be sure no silvering has appeared. If any is present, puncture the film several times with a sharp needle and apply MICRO SOL. The silvering should vanish as the SOL touches it.
10. After the decals have dried for several hours, carefully wash the decal adhesive from the entire model.
11. After the decals have dried for at least 12 hours, complete the model by spraying with either MICRO FLAT or MICRO GLOSS, depending on the sheen desired on the finished model.

72nd Scale  
NO.  
48-75



A-4M SKYHAWKS  
MICROSCALE DECAL  
BY KRASEL INDUSTRIES, INC. SANTA ANA, CA. 92705


AIRCRAFT

3. THE NEXT STEP IS TO CUT A PIECE OF THE TREE FROM THE KIT AT ABOUT 1 1/16" AND SAND SO THAT IT LOOKS LIKE THIS AND IS ABOUT 1" LONG



4. THEN GLUE POD ON TO TAIL SO THAT THE END OF IT LINES UP WITH THE END OF THE RUDDER. FINALLY, USING BODY PUTTY, FILL IN SMALL SECTION UNDER POD AS SHOWN. SAND AND PAINT AS DIRECTED.

DARK AREA TO BE FILLED IN




A-4M 158193

VMA-331

CHERRY POINT, N.C.

OVERALL AIRCRAFT GULL GREY. UNDERSIDE OF WINGS AND FUSELAGE WHITE. ANTI-GLARE PANEL BLACK.



RESEARCH AND INFO COURTESY DON GARRETT


RECOMMENDED KIT: ESCI SCALECRAFT A4M/N SKYHAWK II

The International Plastic Modelers Society is an organization devoted to developing the plastic modeling art. It was formed "By Modelers - For Modelers". If you wish to expand your modeling talents, write for further information to: IPMS/USA, New Member Information, P.O. Box 2555, Long Beach, Ca., 90801;



A-4M 2960th SKYHAWK  
 DELIVERED TO VMA-331  
 CHERRY POINT, N.C.


FLAGS FROM ELEVEN COUNTRIES OPERATING SKYHAWKS,  
 INCLUDING: NEW ZEALAND, ISRAEL, AUSTRALIA, US  
 KUWAIT, SINGAPORE AND ARGENTINA. BLUE STRIPES ON  
 SIDES OF ENGINE INTAKES AND ON TOP OF AIRCRAFT  
 (FS 15182). REST OF PLANE GULL GREY, EXCEPT UNDER-  
 SIDE OF FUSELAGE, WHICH IS WHITE.



A-4M 159491  
 VMAT-102  
 EL TORO MCAS, CA.

OVERALL AIRCRAFT GULL GREY. UNDERSIDE OF  
 WINGS AND FUSELAGE WHITE. ANTI-GLARE  
 PANEL BLACK.

PAINT ENTIRE TAIL RED (FS 21302) FIRST,  
 THEN APPLY LETTERS AND NUMBERS. (BOTH SIDES)



RESEARCH AND INFO COURTESY DON GARRETT