

American Jabos

Thunderbolts Part IV 405 F.G.







Suggested Kit: Hasegawa P-47 Family



American Jabos

Thunderbolts Part IV 405 F.G.

"NAMEE TANHEEL"
PATO-DATE "NAMEE TANHEEL" Senal number 27091 of \$10 F.S. 405 F.G., for PATO-DATE TANHEEL TANHE




P-47D-20-RE, SNI 42-76528, 509 F.S., 405 F.G. flown by LI. William Downey. 12° 2° Curtiss electric prop. External wedge type minor on windscreen. Camoutlaged as per early version of A/C 1, but with Red cancey framing. Possibly used covered wheel hubs. Natural Metal prop spinner.



"TALLAHASSEE LASSIE"
THUNDERBOLT


"TALLAHASSEL ASSES" Senta number Senta number Senta number Senta number Senta Nacia Color Senta Nacia Color Senta Nacia Color Senta Senta

P-47D-30-RA









Decaling: Apply decals only to a glossy surface.

1. With a sharp scissors or knife, carefully cut item to be used, being careful of not cutting off the clear film around it or that belonging to an adjacent item.

2. Submerge in clean tap water for over 10 seconds and lay over an absorbent paper towel. Decal will slide freely in about 20 seconds. Do not leave decal on water bowl over ten seconds, or adhesive quality will suffer. 3. With a clean brush, apply a setting solution to the area where the decal will finally lay. (Micro, Super or Aero Set will do). With a clean pointed brush slide the decal on to the final area. Allow

the setting solution to dry for about 3-5 minutes. 4. With another clean brush, apply a solvent solution over the decal (Micro, Super or Aero Sol will do). Do this if possible in one stroke since your decal will soften up and wrinkle immediately.

This is an important step in the process, whatever you do DO NOT TOUCH THE DECAL, after this process until it is totally dry, preferably overnight.

5. When thoroughly dry, rinse your model with tap water and mild soap to wash of excess glue.

6. Finish your model with the desired final coat (gloss, flat, or semi-gloss).



