

EAGLE STRIKE



productions

48025


F-14 TOMCATS

PART 2

USS CONSTELLATION
USS JOHN F. KENNEDY



Recommended Kit: Hasegawa F-14A




A/C Profile

A/C Type	F-14A Tomcat s/n 159629
Unit	Lcdr Palmer & Lovelady
Locale & Date	USS Constellation.
Camouflage & Markings	Gloss Gull Gray upper surfaces and Gloss White undersurfaces. Notice rudders and upper stabilizers are also Gloss White.
Remarks	Natural Metal wing and vertical fin leading edges. Use striped decal for the arrestor hook. Use Blue trim to patch up the bottom of parts 14, 15, 16, 17 if necessary.

NOTE TO MODELLERS

We recommend that before painting, you trim your vertical stabs / rudder to a perfect fit (DO NOT ATTACH). Then paint and decal the A/C as well as vertical fins. When everything is dry, attach them using cyano glue. It Works!



Notice that bottom sections of parts 14-17 are a little longer than seems necessary. This is to compensate for the fin fairings. Apply using the little notch to align with the rudder. Then trim any excess and apply the assembly as outlined in the note to modellers.




A/C Profile

A/C Type	F-14A Tomcat s/n 159421
Unit	Cdr. Dwight Jones, VF-14
Locale & Date	USS John F. Kennedy
Camouflage & Markings	As above, with all Gloss White vertical tail surfaces and radome.



48025

Stencils for the F-14 are available from Aeromaster 148-023 Hi Vis and 148-024 Low Vis.



EAGLE STRIKE
 productions

EAGLE STRIKE
 Productions
 2025 S.W. 22 Terrace
 Miami, FL. 33145
 U.S.A

Recommended Kit: Hasegawa F-14A

Reference: - Koku-Fan #9, 1977. Pg. 34
 Koku-Fan #9 1977. Pg. 31

Decaling: Apply decals only to a glossy surface.

1. With a sharp scissors or knife, carefully cut item to be used, being careful of not cutting off the clear film around it or that belonging to an adjacent item.
2. Submerge in clean tap water for over 10 seconds and lay over an absorbent paper towel. Decal will slide freely in about 20 seconds. Do not leave decal on water bowl over ten seconds, or adhesive quality will suffer.
3. With a clean brush, apply a setting solution to the area where the decal will finally lay. (Micro, Super or Aero Set will do). With a clean pointed brush slide the decal on to the final area. Allow the setting solution to dry for about 3-5 minutes.
4. With another clean brush, apply a solvent solution over the decal (Micro, Super or Aero Sol will do). Do this if possible in one stroke since your decal will soften up and wrinkle immediately. This is an important step in the process, whatever you do DO NOT TOUCH THE DECAL, after this process until it is totally dry, preferably overnight.
5. When thoroughly dry, rinse your model with tap water and mild soap to wash of excess glue.
6. Finish your model with the desired final coat (gloss, flat, or semi-gloss).